

Hot keys for BootMenu / BIOS Settings

How to get to your Boot Menu or your BIOS settings? Every PC has different hot-keys that go to these settings. This is a list of PC brands with their corresponding hot-keys.

Manufacturer	Type	Models	Boot Menu	Boot Once	BIOS Key	Change Priority
ACER			Esc, F12, F9		Del, F2	
ACER	netbook	AspireOne, Aspire Timeline	F12		F2	
ACER	netbook	Aspire v3, v5, v7	F12	The "F12 Boot Menu" must be enabled in BIOS. It is disabled by default.	F2	
APPLE		After 2006	Option			
ASUS	desktop		F8		F9	
ASUS	laptop		Esc		F9	
ASUS	laptop	R503C	F8		DEL	
ASUS	netbook	Eee PC 1025c	Esc		F2	Boot Tab, Boot Device Priority, 1st Boot Device, Removable Device, F10
COMPAQ		Presario	Esc, F9		F10	BIOS "Advanced Tab", Boot Order
DELL	desktop	Dimension, Inspiron, Latitude	F12	Select "USB Flash Drive"	F2	
DELL	desktop	Inspiron One 2020, 2305, 2320, 2330 All-In-One	F12	Select "USB Flash Drive"	F2	
DELL	laptop	Inspiron	F12	Select "USB Storage Device"	F2	Settings->General->Boot Sequence->"USB Storage Device", then up arrow, [Apply]--[Exit]

DELL	laptop	Precision	F12	Select "USB Storage Device" from boot menu	F12	
EMACHINES			F12		Tab, Del	
HP	generic		Esc, F9		Esc, F10, F1	
HP	desktop	Media Center	Esc		F10	BIOS "Advanced" tab, Boot Order, Move "USB Device" before "Hard Drive"
HP	desktop	Pavilion 23 All In One	Esc	Select boot media from the menu	F10	BIOS "Advanced" tab, Boot Order, Move "USB Device" before "Hard Drive". For non-UEFI media, disable secure boot and enable legacy support
HP	desktop	Pavilion g6 and g7	Esc		F10	BIOS "Advanced" tab, Boot Order, Move "USB Device" before "Hard Drive"
HP	desktop	Pavilion HPE PC, h8-1287c	Esc	Then F9 for "Boot Menu"	Esc F10	Storage tab, Boot Order, Legacy Boot Sources
HP	desktop	Pavilion PC, p6 2317c	Esc	Then F9 for "Boot Menu"	Esc F10	Storage tab, Boot Order, Legacy Boot Sources
HP	desktop	Pavilion PC, p7 1297cb	Esc	Then F9 for "Boot Menu"	Esc F10	Storage tab, Boot Order, Legacy Boot Sources
HP	desktop	TouchSmart 520 PC	Esc	Then F9 for "Boot Menu"	Esc F10	Storage tab, Boot Order, Legacy Boot Sources
HP	laptop	2000	Esc	Select "Patriot Memory" on the Boot Option Menu	Esc	
HP	notebook	Pavilion	Esc		F10	BIOS "Advanced" tab, Boot Order, Move "USB Device" before "Hard Drive"
HP	notebook	ENVY dv6 and dv7 PC	Esc	Then F9 for "Boot Menu"	Esc	F10 Storage tab, Boot Order, Legacy Boot Sources

INTEL			F10	
LENOVO	desktop		F12, F8, F10	F1, F2
LENOVO	laptop		F12	F1, F2
LENOVO	laptop	IdeaPad P500	F12 or Fn + F11	F2
NEC			F5	F2
PACKARD BELL			F8	F1, Del
SAMSUNG			F12, Esc	
SAMSUNG	netbook	NC10	Esc	F2 Boot Tab, Select "Boot Device Priority", Press Return, Up/Down to Highlight, F6/F5 to change priority
SAMSUNG	ultrabook	Series 5 Ultra and Series 7 Chronos	Esc	F2 Boot Tab, Select "Boot Device Priority", Press Return, Up/Down to Highlight, F6/F5 to change priority
SHARP				F2
SONY		VAIO, PCG, VGN	F11	F1, F2, F3
SONY		VGN Esc	F10	F2 BIOS "BOOT" section, "External Device Boot" enabled
TOSHIBA		Protege, Satellite, Tecra	F12	F1, Esc
TOSHIBA		Equium F12	F12	F12